



## Soudatherm Roof 250

## Revision: 7/10/2019

## Page 1 from 3

#### **Technical data**

Basis	Polyurethane
Consistency	Stable foam adhesive , thioxotrpic
Curing system	Moisture curing
Skin Formation (FEICA TM 1014)	8 min
Insulation factor (DIN52612)	Ca. 36 mW/m.K
Curing time	40 minutes for a bead of 30 mm
Yield	Up to 14 m <sup>2</sup> of insulation
Fire rating (DIN4102)	B1
Temperature resistance**	-40 °C till +90 °C (cured)
** This information values to fully avoid avoid and	

\*\* This information relates to fully cured product.

Soudal NV uses test methods approved by FEICA designed to deliver transparent and reproducible test results, ensuring customers have an accurate representation of product performance. FEICA OCF test methods are available at: http://www.feica.com/our-industry/pu-foam-technology-ocf . FEICA is a multinational association representing the European adhesive and sealant industry, including one-component foam manufacturers. Further information at: www.feica.eu

## **Product description**

Soudatherm Roof 250 is a gun applied ready to use single component self-expanding polyurethane adhesive foam. The product has been developed for clean, efficient, economic and permanent bonding of insulation panels and lightweight decorative elements in wall and roof areas. It has been fitted with the unique patented Click&Fix adaptor system for maximum comfort during application.

## **Properties**

• Easy and fast applications (saving of up to 30 % in labour time).

- Good adhesion on all surfaces (except PE, PP and PTFE).
- Fast curing
- Very precise to dose.
- Does not age or rot, but should not be
- exposed to UV radiation.
- Resistant to cold and heat
- Resistant to wind forces
- Freon free (not harmless to ozone layer and greenhouse effect)
- Extremely light
- · Water repellent but not waterproof.
- Open time: Max 8 min
- · Resistant against wind aspiration
- Solvent free
- · Doesn't attack polystyrene.

## Applications

Bonding of common insulation materials

- PIR/PUR covered with
- o Mineral-coated glass fibre
- o Bituminous glass fibre (Sand surfaced or chipped, not on burnable PP surfaces)
- o Aluminium
- Expanded polystyrene (EPS)
- Mineral insulation materials (e.g. Perlite, Multipor®, Fermacell®)
- Mineral wool (but on flat surfaces, Soudatherm Roof 170 is a better bonding solution)

On many types of surfaces:

- Insulation on insulation (multi-layer)
- Even and uneven surfaces
- Masonry surfaces (e.g. concrete, fibre cement, cellular concrete)
- Steel roof decks
- Bituminous roofing felts, sand surfaced or chipped
- Wooden boards, hard PVC, plaster,...
- On vapour barriers:
- o Check the technical data sheet of the vapour barrier to make sure it is suitable for insulation bonding
- o To be tested prior to use or used only with approval of the manufacturer of the barrier
- o Bituminous vapour barriers are possible
- o Aluminium coated vapour barriers: only
- with the approval of the manufacturer

Remark: This technical data sheet replaces al previous versions. The directives contained in this documentation are the result of our experiments and of our experience and have been submitted in good faith. Because of the diversity of the materials and substrates and the great number of possible applications which are out of our control, we cannot accept any responsibility for the results obtained. Since the design, the quality of the substrate and processing conditions are beyond our control, no liability under this publication is accepted. In every case it is recommended to carry out preliminary experiments. Soudal reserves the right to modify products without prior notice.





## Soudatherm Roof 250

## Revision: 7/10/2019

- Doesn't bond on PP, PE or PTFE (Teflon)
- Always perform a prior adhesion test

### Packaging

Colour: orange Packaging: 800 ml aerosol (net)

#### Shelf life

24 months unopened and stored in dry and cool conditions (Between 5 and 25 °C), Upright storage is recommended. After application, just lock the gun and it's closed. If the product will not be used within the following week, clean can and gun with Soudal Gun & Foam Cleaner. After cleaning, remove the Soudal Gun & Foam Cleaner and empty the gun completely.

# Application method Gluing

• The materials should be clean and free of dust and grease. Loose parts should be removed and the surface should be coated with a primer if necessary.

• For renovation and especially ballasted roofs, make sure the bonding surface is firmly attached to the substructure.

• Shake at least 20 seconds with the can upside down to ensure proper mixing of the ingredients and maximum yield.

• Thread the can tightly to the Applicator Gun.

• Adjust extrusion rate to allow for 30mm beads using the setting screw at the end of the applicator gun.

• Apply directly onto the surface, holding the gun at an angle of about 90° to the surface and ensure a distance of about 1 to 2 cm between nozzle and surface. The nozzle should not be in direct contact with the surface.

It is recommended that at least 4 beads / m (30mm diameter) should be applied (80 to 100 g/m<sup>2</sup>). On the corners and the edges of the roof, at least 8 beads are recommended. The correct number of beads (and thus the usage of adhesive) can be calculated according to EN 1991-1-4. The region, the roof area, the location and structure height and also the location on the roof (middle, corners or edges) are factors that have to be taken into account.
On uneven surfaces (for example old bituminous roofing felts), more adhesive (thicker beads up to 50mm) needs to be applied in order to make sure that there is at

least 40% adhesive transfer between surface and insulation panel.
Maximum allowed unevenness underneath

 Maximum allowed unevenness underneath an insulation board is 1cm.

• After extrusion, the panels need to be pressed down in the adhesive beads within the open time of 8 minutes. Then do not walk on the applied insulation panels for about 1 hour.

• It's recommended to shake the can after each work interruption.

Do not hammer on the boards

• When the boards are pulled back or displaced (and the adhesive layer is broken), it's necessary to apply extra adhesive to get a good bond.

The installer should make sure that the adhesive is fully cured before applying the roofing membrane to the insulation board, minimize walking over the boards during the first hour (especially on uneven surfaces).
Cured adhesive should be removed mechanically.

#### Filling

• Shake at least 20 seconds with the can upside down to ensure proper mixing of the ingredients and maximum yield.

• Thread the can tightly to the Applicator Gun.

• It's recommended to shake the can after each work interruption.

• When the product is applied in multiple layers, moisten the surface between each layer.

Remark: This technical data sheet replaces al previous versions. The directives contained in this documentation are the result of our experiments and of our experience and have been submitted in good faith. Because of the diversity of the materials and substrates and the great number of possible applications which are out of our control, we cannot accept any responsibility for the results obtained. Since the design, the quality of the substrate and processing conditions are beyond our control, no liability under this publication is accepted. In every case it is recommended to carry out preliminary experiments. Soudal reserves the right to modify products without prior notice.

#### Page 2 from 3





# Soudatherm Roof 250

## Revision: 7/10/2019

• If not yet cured, use Soudal Gun and Foam Cleaner for cleaning. Cured adhesive should be removed mechanically.

Can temperature: +5 °C - 35 °C Ambient temperature: +5 °C - 30 °C. Surface temperature: +5 °C - 35 °C

#### **Health- and Safety Recommendations**

Take the usual labour hygiene into account. Always wear gloves and goggles. Remove cured foam mechanically. Never burn away. Consult label and material safety data sheet for more information. When vaporizing (for example with a compressor), additional security measures will be required.

#### Remarks

• Moisten surfaces with a water sprayer prior to application. If you have to work in layers repeat moistening after each layer. For not common surfaces we recommend an adhesion test.

#### Standards and certificates

- Fire Class B1 (DIN 4102-1) Test Certificate P-SAC 02/III-453 (MFPA Leipzig)
- BDA (Gorinchem) 0050-L-16/1: Utherm Roof PIR-L on Sopravap Stick C-15

 BDA (Gorinchem) 0053-L-16/1: Rockwool Rhinoxx on Sopravap Stick C15

• BDA (Gorinchem) 0076-L-17/1 - 0077-L-17/1: IDEAL EPS 120 on Bueho ALGV E 40 Plus

• BDA (Gorinchem) 0197-L-14/1: Bondrock MV on Hassodritt Vapor

• BDA (Gorinchem) 0293-L-13/1: Linitherm PAL (SK) on Mogat Mogaplan

 Carlisle Europe 08/08/2013: Kingspan TR27 on PDT ALUTRIX 600/FR

- IFI ( Aachen ) PB 22/09 EPS 40
- IFI (Aachen) PB 23/09 Powerdeck F

WTCB CAR 14180-2: Unilin PIR K on IREX
Profil

• WTCB CAR 14224-1: Poliuretanos PIR 7C on Firestone V-Force EU

- Page 3 from 3
- WTCB CAR 14233: IKO Enertherm MG on Seal Eco Alushell 0,6 mm
- WTCB CAR 16067-3: IKO Enertherm ALU
   on MEPS 25
- WTCB CAR 16219: ISOMO on MEPS 25
- WTCB CAR 19-070-01: Utherm Roof PIR-K on Siplast Irex Profil
- WTCB CAR 19-233-01: Utherm Roof PIR-K on Imper Unovel 25

Remark: This technical data sheet replaces al previous versions. The directives contained in this documentation are the result of our experiments and of our experience and have been submitted in good faith. Because of the diversity of the materials and substrates and the great number of possible applications which are out of our control, we cannot accept any responsibility for the results obtained. Since the design, the quality of the substrate and processing conditions are beyond our control, no liability under this publication is accepted. In every case it is recommended to carry out preliminary experiments. Soudal reserves the right to modify products without prior notice.